ALLEN&HEATH



GL4800

SERVICE INFORMATION

Publication AP6151

Introduction

This publication provides technical information on servicing the Allen & Heath GL4800. Included are internal layout drawing, block diagram and circuit schematics with board layouts and spare parts lists. Whilst we believe this information to be reliable we do not assume responsibility for inaccuracies. We also reserve the right to make changes in the interest of further product development.

Additional Resources

Allen & Heath web site <u>www.allen-heath.com</u> Product information

Technical downloads Distribution contacts Company contacts

Technical support support@allen-heath.com See web for local contact

GL4800 User Guide AP6150 Operating instructions

Performance specification

GL4800 AP6152 Fitting instructions

SYS-LINK Fitting Instructions

GL4800 AP6285 System Description

SYS-LINK Applications Note Cabling Details

GL4800 Service Information

Issue status: gl4800_ap6151_1.doc

Print date: 01 July 2005

Copyright © 2005 Allen & Heath. All rights reserved

ALLEN&HEATH

Kernick Industrial Estate, Penryn, Cornwall, TR10 9LU, UK http://www.allen-heath.com



Servicing Precautions – General Notes

Service personnel: Service work should be carried out by technically qualified service personnel only.

Mains power is dangerous and can kill. Do not attempt to work on a linear or switched mode power supply if you are not suitably qualified to do so. Do not attempt to repair surface mount circuit assemblies unless you are suitably qualified and have the

necessary facilities to do so. Replacement circuit assemblies can be ordered.

Service facilities: Ensure a suitably sized work surface is available. Ensure this is clear of dirt, debris

and obstructions which may damage the equipment surfaces. Ensure adequate lighting. Use the correct tools for the job and ensure they are in good working order.

Ensure all workshop safety requirements are adhered to.

Service information: Check that you have all the information you need before starting the service job. Refer

to the Allen & Heath web site or contact Allen & Heath technical support for details on the latest information. Full technical information can be downloaded from the web site

Distributor Zone (password required).

Mains power: Connect the equipment to mains power only of the type described in the user guide

and marked on the rear panel. The power source must provide a good ground connection. Ensure you always use an isolation transformer when working on any

mains power supply unit.

Mains cord and fuse: Use the correct power cord as supplied with the equipment. Do not remove or tamper

with the ground connection in the power cord. Heed the Important Mains Plug Wiring Instructions printed in the user guide if it is necessary to rewire the mains cord. Always replace the equipment mains fuse with the correct type and rating as

described in the user guide and marked on the equipment panel.

Opening the unit: Switch off and remove the mains power cord before opening the equipment. Ensure

all power supply covers and safety shields are in place before applying power with the

unit open for diagnostic fault finding.

Closing the unit: Before finishing, check the quality and accuracy of the service work carried out.

Remove any dirt or debris as this may cause equipment failure in the future. Ensure all assemblies, harnesses and connectors are correctly aligned and plugged in. Ensure that jumper settings and control configurations are correctly set according to the

requirements of the customer.

Testing the unit: Before operating the equipment, read and adhere to the Important Safety Instructions

printed in the user guide. Test that the service work has been successfully carried out.

Shipping the unit: Use adequate packing such as the original packaging or purpose designed flight case

if you need to ship the unit. To avoid injury to yourself or damage to the equipment

take care when lifting, moving or carrying the equipment.



Servicing Notes - GL4800

User maintenance: There are several user configurable jumper links inside. These are described in the

user guide together with instructions on how to change the default settings.

Technology: The GL4800 uses conventional thru-hole and SMT (surface mount) PCB

technology. In certain cases it may be better to replace a faulty assembly rather than try to fix it without the appropriate tools and training. The console uses a rack mountable external linear power supply (RPS11). Due to the mains voltages present

in the power supply, it should be serviced by suitably qualified personnel only.

Operation: To test the console make sure it is connected as described in the user guide. Check

that the voltage setting on the power supply rear panel is correct for the local mains

supply.

Fault finding: For effective fault diagnosis trace the signal flow through the circuit path. Refer to the


system block diagram. Replacement circuit assemblies are available from Allen &


Heath.


gl4800_ap6151_1.doc


Contents Log

Internal Layout drawing	gl4800_layout_1.pdf
Surface and Main Parts	gl4800_parts_1.pdf
System Block Diagram	gl4800_blockdiagram_1.pdf
Master PCB	gl4800_002-165_master_2.pdf
Slave PCB	gl4800_002-167_slave_1.pdf
MPU PCB	gl4800_002-198_mpu_2.pdf
Mono Input PCB	gl4800_003-410_mono_input_2.1.pdf
Stereo Input PCB	gl4800_003-411_stereo_input_3.1.pdf
Group PCB (A,B & C)	gl4800_003-412_413_414_group_3.3.pdf
Mono PCB	gl4800_003-415_mono_3.2.pdf
8M Connector PCB	gl4800_003-416_8m_conn_2.pdf
4SM Connector PCB	gl4800_003-417_4sm_conn_2.pdf
4MS Connector PCB	gl4800_003-418_4ms_conn_2.pdf
8S Connector PCB	gl4800_003-419_8s_conn_2.pdf
Master Connector PCB	gl4800_003-420_master_conn_3.pdf
Power Connector PCB	gl4800_003-423_power_conn_b.pdf
Mix Amp Sub PCB	gl4800_003-452_mix_amp_sub_1.pdf
GL Series Meter PCB	glseries_meters_3.pdf














003-411 iss.3.1

























003-417 iss.2



























003-415 iss.3.2




003-415 iss.3.2










002-165 iss.2











002-167 iss.1





























002-198 iss.2





002-198 iss.2






GL Meters iss.3





GL4800 Internal Layout

(GL4800-824B shown)




Product	GL4800-824m
	GL4800-832m
	GL4800-840m
n =	
٩	
34 stereos	to right of masters
C 4 stereos	on right of console
D 8 stereos	on right of console
Master PCB	002-165
Slave PCB	002-167
MPU PCB	002-198
Mono Input PCB	003-410
Stereo Input PCB	003-411
Group A PCB	003-412
Group B PCB	003-413
Group C PCB	003-414
Mono PCB	003-415
BM Connector PCB	003-416
4SM Connector PCB.	003-417
4MS Connector PCB.	003-418
3S Connector PCB	003-419
Master Connector PC	B 003-420
Meters 1-6 PCB	003-421
Meters Master PCB	003-422
Power Connector PC	3 003-423
Mix Amp Sub PCB	003-452

SYS-LINK In PCB + Harness ... 003-462



GL4800 Surface Parts



GL4800 Surface Parts

(GL4800-824B shown)

